

Luma IPC Pinout Chart

In certain situations, you may need to cut the tail of a Luma IP camera (or perhaps someone already cut it). In such cases, you need to know how to wire it.

Pin Functions

The pin functions are as follows:

1. Data (TX +)
2. Data (TX -)
3. Data (RX +)
4. Ground (-)
5. Ground (-)
6. Data (RX -)
7. Power (+)
8. Power (+)

Wire Colors

Depending on the camera model and date of manufacture, your Luma IP camera tail has one of two sets of wires. These are wired to your network as shown below.

